


Installation and operating instruction
 Installations- und Betriebsanleitung
 Montage- en bedieningsvoorschriften

Instructions d'installation et d'utilisation
 Instrucciones de instalación y uso
 Istruzioni per l'installazione e l'uso

<p>SPIROTECH FOR BEST PERFORMANCE</p>		<p>SPIROTRAP® MBL</p>	
<p>installator date instalatorul dată</p>	<p>instalatiecodum data d'instalatiun</p>	<p>fecha de instalacion data d'instalacione</p>	<p>location instalatorisort</p>
<p>installatieopties plata d'instalatiun</p>	<p>lugar de instalacion lugar d'instalacione</p>		



Dirt Separator
 Schlammabscheider
 Vuilafscheider
 UE125WJ
 Separator de boues
 Separatore di impurità
 Separator de lodos
 UE150WJ
 UE200WJ



0 ... bar
 0 ... °C
 Acc.PED (97/23/EC) S3.3

1

> 270 mm
 > 270 mm
 ≤ 50% glycol

2

Rp 1 1/4
 Rp 1 1/2
 Rp 2
 > 225 mm

3

4

max. 40 Nm
 click

5

Pmax = 1,5 x ...bar
 click

6

7

7